



ELEVATE YOUR BUSINESS.

# eGalaxWorks PCAP Touch Diagnostic Tool

© COPYRIGHT 2016 FIRICH ENTERPRISES CO., LTD. ALL RIGHTS RESERVED.

# (Content / Agenda)




I- Tool

II- Test Method

# Test Method- eGalaxSensorTester3



1. Run eGalax Sensor Tester3.exe. It will do auto-detection.




2. The utility will proceed to check and update firmware automatically.




# Test Method- eGalaxSensorTester3

- If there is **NO-LINK** message indicates connection problem. Reconnect the touch cable.





- If connection is established, **LINK** message is shown



# Test Method-eGalaxSensorTester3



- Do 10 fingers touch test





**ID[0]: 121Hz  
ID[1]: 121Hz  
ID[2]: 121Hz  
ID[3]: 120Hz  
ID[4]: 120Hz  
ID[5]: 118Hz  
ID[6]: 120Hz  
ID[7]: 118Hz  
ID[8]: 122Hz  
ID[9]: 122Hz**

**Check Report Rate, Retry = 1  
EETI OPDraw v2.1.0.6  
TestID(2) : Max Count & Reprot Rate Test  
Timer: 9 (100)  
Put 10 Fingers on Touch Panel in 100 seconds  
Number of Contacts:**

# Test Method-eGalaxSensorTester3



- Four edges test




Must draw line in the red box

**EETI OPDraw v2.1.0.6**  
**TestID(3) : 4 edge test (Single)**  
**Timer: 9 (120)**  
**Monitor Position : (-1, -1 ),Raw Position : (-1, -1 ),0 hz**  
**Retry Count:40**

# Test Method-eGalaxSensorTester3





- Four edges test with simultaneous target press



# Test Method-eGalaxSensorTester3




13 points individual touch test



Cross Line drawing test


# Test Method-eGalaxSensorTester3



# Test Method-eGalaxTuner31XX



- Abnormal signal activity check




- Run eGalaxTuner31XX leave undisturbed for extended period

# Test Method-eGalaxTuner31XX




- Select Touch info to check signal indicator log lines should not have any large spikes



# Test Method-eGalaxTuner31XX



- Select Image Data tab




- Choose Touch signal at Normal Mode
-

# Test Method-eGalaxTuner31XX



- Normal data value should be within -2~2  
Anything outside of the range will be shown in color



# Test Method



- If the touch is not working properly, after testing, can't find abnormality, please send log file to FEC for analysis.
- Or send touch assembly to FEC for analysis .



Thank You.